



Biological Waste Disposal Table

Type Of Waste	Container for Disposal or Treatment	Local Treatment	Where To Put For Pick-up	Picked Up By
Animal bedding from infected animals	Place cage, water bottle and bedding in clear autoclave bag as directed by RAR. (If animals housed outside of RAR, return bag to RAR)	Autoclaved by RAR staff.	Place autoclaved bedding in regular trash.	FM
Animal carcasses and tissue	RAR designated red barrel for carcasses	None	See RAR Animal Care Services for the location of animal coolers.	FM
Human organs, tissue, or body parts (pathological waste)	Call Bequest Program 625-1111	None	Call Bequest Program 625-1111	Call Bequest Program 625-1111
Liquid infectious waste including all rDNA material	Place in a suitable liquid handling container.	Disinfect with 1 part bleach to 10 parts liquid, or other appropriate disinfectant per an IBC approved protocol, and sewer. Can also autoclave and sewer. (Do not sewer agar, handle as solid waste.)	Not applicable	Not applicable
Contaminated non-sharps (including rDNA)	Clear autoclave bag such as U Stores # CX10014 or # CX10034 or	Autoclave at 121°C for 60 min See Autoclaving Biological Waste	After autoclaving place in regular waste container	FM
	Red infectious waste bag such as U Stores # MS79723	None	Next to regular lab trash container NOTE: Red bags cannot be placed in hallways or other public areas	Call 624-2900 for a pick-up request if biohazardous material is not normally picked up in your area
Glass (not contaminated with hazardous material)	Dedicated box closed and taped shut (Use separate boxes for broken and non-broken glass and label as such)	None	Next to regular lab trash container	FM

